

---

# ***VISTA-100***

---

## **COMMERCIAL FIRE/BURGLARY PARTITIONED SECURITY SYSTEM** with SCHEDULING

**Quick Start**  
Step-by-Step Programming Procedure  
Single And Multiple Partition Programming Forms  
System Worksheets



# TABLE OF CONTENTS

RECOMMENDED PROGRAMMING PROCEDURE.....	3
PROGRAM FIELD CATEGORIES .....	5
VISTA-100 SINGLE PARTITION PROGRAMMING FORM.....	6
VISTA-100 MULTIPLE-PARTITION PROGRAMMING FORM.....	10
PROGRAMMING WITH #93 MENU MODE .....	15
SYSTEM LAYOUT WORKSHEETS .....	16

---

The purpose of this document is to provide a quick and easy way to program your entire system. A recommended programming procedure is included, followed by a list of program fields with the corresponding program group they belong to (system-wide, partition-specific, scheduling, etc.). Two program forms are included, one for a single-partition system, and the other for a multiple partition system. If you are setting up a single-partition system, the partition-specific fields become system-wide fields.

Following the program forms are system layout worksheets. We recommend that you use these sheets to plan your system before programming is performed. If you need further information about specific programming options, see the VISTA-100 INSTALLATION INSTRUCTIONS.

## Two programming forms are provided: Single Partition Form and Multiple-Partition Form

- Make sure that one two-line alpha keypad is connected to the control and is set to device address "00."

### Single Partition System

- The system default is for a single partition system. Use the VISTA-100 SINGLE PARTITION PROGRAMMING FORM beginning on page 6 when programming for single partition usage. Follow the steps outlined on page 3 of this document for proper programming procedure.

### Multiple-Partition System

- You must enter the number of partitions you are using in data field 2\*00 to set the system for multiple partitions. Use the VISTA-100 MULTIPLE-PARTITION PROGRAMMING FORM beginning on page 10 when programming the system for multiple partitions. Follow the steps outlined on page 3 of this document for proper programming procedure.

## SUMMARY OF PROGRAMMING COMMANDS

- |  |
|--|
| <ul style="list-style-type: none"><li>• <b>To enter program mode</b>, enter installer code + [8] + [0] + [0] + [0]</li><li>• <b>To set standard defaults</b>, press *97</li><li>• <b>To set communication defaults</b>, press *94 + one of the following: *80=low speed; *81=Ademco Express; *82=Ademco High Speed; *83=Ademco's Contact ID</li><li>• <b>To change to next page of program fields</b>, press *94</li><li>• <b>To return to previous set of fields</b>, press *99</li><li>• <b>To erase account &amp; phone number field entries</b>, press [*] + field number + [*]</li><li>• <b>To assign zone descriptors</b>, press #93 + follow menu prompts</li><li>• <b>To add custom words</b>, press #93 + follow menu prompts</li><li>• <b>To enter Installer's Message</b>, press #93 + follow menu prompts</li><li>• <b>To exit program mode</b>, press *99 OR *98: *99 allows re-access to programming mode by installer code. *98 prevents re-access to programming mode by installer code.</li></ul> |
|--|

Standard default (\*97) values are shown in brackets [ ], otherwise default = 0.

## Recommended Programming Procedure

The following is a step-by-step procedure recommended for programming your VISTA-100 system.

- 1. Set the keypads (and other peripheral devices) to the appropriate addresses.**
- 2. Set factory defaults by pressing \*97.**  
This will automatically enable keypad addresses 00-03, so be sure at least one keypad is set to one of these addresses.
- 3. Program system-wide (global) data fields.**  
Using the programming form as a guide, enter program mode and program all system wide programming fields. These options affect the entire system, regardless of partitions. They include control options, downloader and dialer options, RF options, event logging options, etc. Refer to the COMPLETE LIST OF PROGRAMMING FIELDS for a listing of the program fields arranged by function.  
**Note that field 2\*00 (number of partitions) & field 1\*32 (RF expander type) must be programmed before continuing.**
- 4. Program partition-specific fields.**  
When the system-wide fields have been programmed, program all partition-specific programming fields by first pressing \*91 to select a partition (while still in data field program mode). Then enter the first partition-specific field number \*09. The next partition-specific field will automatically be displayed when you are finished entering the value for field \*09. Partition-specific fields can have different values for each partition. To program the fields for the next partition, press \*91, enter the desired partition number, then enter field \*09. Refer to the MECHANICS OF PROGRAMMING section for detailed instructions.
- 5. Use #93 Menu Mode for device programming.**  
Refer to the DEVICE PROGRAMMING section to assign keypad ID numbers and default partitions for each keypad, and to selectively suppress certain keypad sounding options. Also use this mode to assign RF receivers, relay modules, and the VIP module.
- 6. Use #93 Menu Mode for zone programming.**  
Refer to the ZONE PROGRAMMING section to program zone response types, assign right loop zones and wireless zones, assign zones to partitions, and to program alarm report codes.
- 7. Use #93 Menu Mode for programming relays.**  
Refer to the RELAY PROGRAMMING section to program desired relay operation.
- 8. Program Communication options.**  
Refer to the COMMUNICATION PROGRAMMING section for further instructions to load communication defaults and to program related fields. Then use #93 mode to program report codes if necessary.
- 9. Use #93 Menu Mode for programming alpha descriptors.**  
Refer to the ALPHA PROGRAMMING section to enter zone and partition descriptors and a custom installer's message.

- 10. Use #93 Menu Mode for programming relay voice descriptors and custom word substitutes.**  
Refer to the RELAY VOICE DESCRIPTORS section for further instructions for programming relay descriptors to be announced by the 4285 VIP module, as well as the CUSTOM INDEX section for custom word substitutes.
- 11. Use #80 Mode for programming schedules.**  
Refer to the SCHEDULING section to program open/close schedules, temporary and holiday schedules, limitation of access schedules, and time driven events.
- 12. Define user access codes.**  
Refer to SECURITY ACCESS CODES section to program authority level, O/C reporting option, partition assignments, and wireless key assignments for each user.
- 13. Exit Programming Mode**  
Exit programming mode by pressing either \*98 or \*99. A second entry of \*99 is required if the exit is being done from fields 1\*00 and above.  
  
To prevent re-access to Programming mode using the Installer's code, use \*98. The only way to re-access Programming mode is by depressing both the [\*] and [#] keys at the same time within 30 seconds of power up.  
  
Exiting by using \*99 always allows reentry into Programming mode using the Installer's code. Either way of exiting will allow access via downloading. Note that if local programming lockout is set via downloading, programming mode cannot be entered at the keypad.

## PROGRAM FIELD CATEGORIES

In the following pages, the programming fields have been arranged by category. Use this index to cross reference the numerical ordered fields on the programming form.

<b>Field</b>	<b>Group</b>	<b>Field</b>	<b>Group</b>	<b>Field</b>	<b>Group</b>
*00	System-Wide	*83	Communications	1*53	System-Wide
*09	Partition-Specific	*84	Partition-Specific	1*57	System-Wide
*10	Partition-Specific	*85	Partition-Specific	1*58	System-Wide
*11	Partition-Specific	*87	Partition-Specific	1*60	System-Wide
*12	Partition-Specific	*88	Partition-Specific	1*70	System-Wide
*13	Partition-Specific	*89	Communications	1*71	System-Wide
*14	System-Wide	*90	Partition-Specific	1*72	System-Wide
*15	System-Wide	1*01	#93 Menu Mode	1*73	System-Wide
*16	Partition-Specific	1*02	#93 Menu Mode	1*74	System-Wide
*17	System-Wide	1*03	#93 Menu Mode	1*75	System-Wide
*18	System-Wide	1*04	#93 Menu Mode	1*76	Partition-Specific
*19	System-Wide	1*05	#93 Menu Mode	2*00	System-Wide
*20	System-Wide	1*06	#93 Menu Mode	2*01	System-Wide
*21	System-Wide	1*07	#93 Menu Mode	2*02	System-Wide
*22	Partition-Specific	1*08	#93 Menu Mode	2*05	Partition-Specific
*23	Partition-Specific	1*09	#93 Menu Mode	2*06	Partition-Specific
*24	System-Wide	1*17	System-Wide	2*07	Partition-Specific
*25	System-Wide	1*18	Partition-Specific	2*08	Partition-Specific
*26	Communications	1*19	Partition-Specific	2*09	Partition-Specific
*27	Communications	1*20	System-Wide	2*10	Partition-Specific
*28	System-Wide	1*21	System-Wide	2*11	System-Wide
*29	Partition-Specific	1*22	System-Wide	2*13	Communications
*30	Communications	1*23	System-Wide	2*14	Communications
*31	Communications	1*24	System-Wide	2*18	Partition-Specific
*32	Partition-Specific	1*25	System-Wide	2*19	Partitioning
*33	Communications	1*28	System-Wide	2*20	Partition-Specific
*34	Communications	1*29	System-Wide	2*21	System-Wide
*35	System-Wide	1*30	System-Wide	2*22	Partition-Specific
*36	System-Wide	1*31	System-Wide	2*23	Partition-Specific
*37	System-Wide	1*32	System-Wide	2*24	Partition-Specific
*38	Partition-Specific	1*33	Communications	3*00	System-Wide
*39	Partition-Specific	1*34	Communications	3*13	System-Wide
*40	Communications	1*35	Communications	3*14	System-Wide
*41	System-Wide	1*36	Communications	3*15	System-Wide
*42	Communications	1*37	Communications	3*16	System-Wide
*43	Communications	1*38	Communications	3*17	System-Wide
*44	Communications	1*39	Communications	3*18	System-Wide
*45	Communications	1*40	Communications	3*19	System-Wide
*46	Communications	1*41	Communications	3*20	System-Wide
*47	Communications	1*42	Communications	3*21	System-Wide
*48	Communications	1*43	Partition-Specific	3*30	System-Wide
*49	Communications	1*44	System-Wide	3*31	System-Wide
*50	Communications	1*45	Partition-Specific	3*57	Partition-Specific
*51	Communications	1*46	System-Wide	3*58	System-Wide
*52	Communications	1*47	Partition-Specific	3*59	Partition-Specific
*53	Communications	1*48	System-Wide	3*60	Partition-Specific
*79	Communications	1*49	System-Wide	3*61	System-Wide
*80	Communications	1*52	Partition-Specific	3*82	System-Wide
				3*85	System-Wide

# VISTA 100 SINGLE PARTITION PROGRAMMING FORM

- |  |   |
|--|---|
| <p><b>* 00</b> INSTALLER CODE <span style="float: right;">       </span><br/>Enter 4 digits, 0-9 [5140]</p> <p><b>* 08</b> TEMPORAL SIREN PULSE <span style="float: right;">[0] <input type="checkbox"/></span><br/>1 = Yes; 0 = No</p> <p><b>* 09</b> ENTRY DELAY #1 <span style="float: right;">[02] <input type="checkbox"/>  </span><br/>00-15 times 15 seconds<br/>Maximum "03" for UL Commercial Burglary installations.</p> <p><b>* 10</b> EXIT DELAY #1 <span style="float: right;">[03] <input type="checkbox"/>  </span><br/>00-15 times 15 seconds<br/>Maximum "04" for UL Listed installations.</p> <p><b>* 11</b> ENTRY DELAY #2 <span style="float: right;">[06] <input type="checkbox"/>  </span><br/>00-15 times 15 seconds (must be longer than Entry Delay #1)<br/>Maximum "03" for UL Commercial Burglary installations.</p> <p><b>* 12</b> EXIT DELAY #2 <span style="float: right;">[08] <input type="checkbox"/>  </span><br/>00-15 times 15 seconds (must be longer than Exit Delay #1)<br/>Maximum "04" for UL Commercial Burglary installations.</p> <p><b>* 13</b> BELL 1 TIMEOUT <span style="float: right;">[04] <input type="checkbox"/>  </span><br/>01-15 times 2 minutes. Minimum 16 min. for UL Commercial Burglary and 6 min. for Commercial Fire.</p> <p><b>* 15</b> KEYSWITCH ASSIGNMENT <span style="float: right;">[0] <input type="checkbox"/></span><br/>Enter partition in which keyswitch used,<br/>1-8; 9=Silences bells if fire alarm present; 0=disable</p> <p><b>* 16</b> BELL 1 CONFIRMATION OF ARMING DING <span style="float: right;">[0] <input type="checkbox"/></span><br/>1=enable; 0=disable. Must be "1" for UL Burglary Installations.</p> <p><b>* 17</b> AC LOSS KEYPAD SOUNDING <span style="float: right;">[0] <input type="checkbox"/></span><br/>1=yes; 0=no</p> <p><b>* 18</b> BELL 1 AC POWER LOSS ALARM <span style="float: right;">[0] <input type="checkbox"/></span><br/>1=yes; 0=no. Must be "1" for UL Commercial Burglary.</p> <p><b>* 19</b> RANDOMIZE AC LOSS REPORT <span style="float: right;">[0] <input type="checkbox"/></span><br/>1=10-40 min; 2=6-12 hrs; 0=normal report (about 2 min. after AC loss). Must be "2" for Central and Remote Station Fire alarm systems.</p> <p><b>* 20</b> VIP MODULE PHONE CODE <span style="float: right;">   </span><br/>Enter 01 - 09 for the first digit; enter <span style="float: right;">[00] , [00]</span><br/>11 for "*" or 12 for "#" for the second digit. This field<br/>Must be set to "0" for Commercial Fire &amp; UL Commercial Burglary installations.</p> <p><b>* 22</b> KEYPAD PANIC ENABLE [001] <span style="float: right;"><input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/></span><br/>1=enable; 0=disable <span style="float: right;">995 996 999</span></p> <p><b>* 23</b> MULTIPLE ALARMS <span style="float: right;">[1] <input type="checkbox"/></span><br/>1=yes; 0=no</p> <p><b>* 24</b> IGNORE EXPANSION ZONE TAMPER <span style="float: right;">[0] <input type="checkbox"/></span><br/>1=Ignore; 0=Enable tamper for RF and RPMs. Must be "0" for UL installations if using these devices.</p> <p><b>* 25</b> BURG.TRIGGER FOR RESPONSE TYPE 8 <span style="float: right;">[1] <input type="checkbox"/></span><br/>1=enable; 0=disable</p> <p><b>* 26</b> INTELLIGENT TEST REPORTING <span style="float: right;">[0] <input type="checkbox"/></span><br/>1=yes, (no report sent if any other report was recently sent); 0=no.. Must be 0 for Commercial Fire &amp; UL Commercial Burglary.</p> <p><b>* 27</b> TEST REPORT INTERVAL <span style="float: right;">[024]    </span><br/>Enter interval in hours, 001-999; 000=no report ; Max. 024 for Commercial Fire &amp; UL.</p> <p><b>* 28</b> POWER UP IN PREVIOUS STATE <span style="float: right;">[1] <input type="checkbox"/></span><br/>1=yes; 0=no; "1" for UL.</p> <p><b>* 29</b> QUICK ARM <span style="float: right;">[1] <input type="checkbox"/></span><br/>1=yes; 0=no</p> | <p><b>* 30</b> MAIN DIALER (TOUCHTONE OR ROTARY) [0] <input type="checkbox"/><br/>1=TouchTone; 0=rotary</p> <p><b>* 31</b> PABX ACCESS CODE <span style="float: right;">       </span><br/>00-09; B-F (11-15)</p> <p><b>* 32</b> PRIM. SUBS. ACCT # <span style="float: right;">       </span><br/>Enter 00-09; B-F (11-15) [15 15 15 15]</p> <p><b>* 33</b> PRIMARY PHONE NUMBER<br/><span style="float: right;">                   </span><br/><span style="float: right;">           </span><br/>Enter 0-9 for each digit. Enter #11 for *, #12 for #, #13 for 2 second pause</p> <p><b>* 34</b> SECONDARY PHONE NUMBER<br/><span style="float: right;">                   </span><br/><span style="float: right;">           </span><br/>Enter 0-9 for each digit. Enter #11 for *, #12 for #, #13 for 2 second pause</p> <p><b>* 35</b> DOWNLOAD PHONE No.<br/><span style="float: right;">                   </span><br/><span style="float: right;">           </span><br/>Enter 0-9 for each digit. Enter #11 for *, #12 for #, #13 for 2 second pause</p> <p><b>* 36</b> DOWNLOAD ID No.<br/><span style="float: right;">                   </span><br/>Enter 00-09; A-F (10-15) [15 15 15 15 15 15 15 15]</p> <p><b>* 37</b> DOWNLOAD COMMAND ENABLES<br/><span style="float: right;">               </span><br/>Dialer System Not Remote Remote Remote Upload Download<br/>Shutdown Shutdown Used Bypass Disarm Arm Program Program<br/>See field 1*53 for Callback disable option; [1=enable]; 0=disable; For Commercial Fire &amp; UL installations, all entries must be "0."</p> <p><b>* 38</b> PREVENT ZONE XXX BYPASS <span style="float: right;">[00]    </span><br/>001-087; 00 if all zones (except Fire zones) can be bypassed</p> <p><b>* 39</b> ENABLE OPEN/CLOSE REPORT FOR <span style="float: right;">[0] <input type="checkbox"/></span><br/>INSTALLER CODE 1=enable; 0=disable</p> <p><b>* 40</b> OPEN/CLOSE REPORT FOR KEYSWITCH <span style="float: right;">[0] <input type="checkbox"/></span><br/>1=enable; 0=disable</p> <p><b>* 41</b> NORMALLY CLOSED or EOLR (Zones 3-8) <span style="float: right;">[1] <input type="checkbox"/></span><br/>1=N.C.loops; 0=EOLR supervision; Must be "0" for Commercial Fire &amp; UL.</p> <p><b>* 42</b> DIAL TONE PAUSE <span style="float: right;">[0] <input type="checkbox"/></span><br/>0=5 seconds; 1=11 seconds; 2=30 seconds; Must be "0" Commercial Fire &amp; UL.</p> <p><b>* 43</b> DIAL TONE DETECTION <span style="float: right;">[1] <input type="checkbox"/></span><br/>1=wait for true dial tone; 0=pause, then dial</p> <p><b>* 44</b> RING DETECTION COUNT <span style="float: right;">[00]    </span><br/>01-14; 15=answering machine; 00=no detection. Must be "00" for Commercial Fire &amp; UL Burglary.</p> <p><b>* 45</b> PRIMARY FORMAT <span style="float: right;">[0] <input type="checkbox"/></span><br/>0=Low Speed; 1=Contact ID; 2=Ademco High Speed; 3=Ademco Express</p> <p><b>* 46</b> LOW SPEED FORMAT (Primary) <span style="float: right;">[0] <input type="checkbox"/></span><br/>0=Ademco Low Speed; 1=Sescoa/Radionics</p> |
|--|---|

- \* 47 SECONDARY FORMAT [0]   
0=Low Speed; 1=Contact ID; 2=Ademco High Speed;  
3=Ademco Express
- \* 48 LOW SPEED FORMAT (Sec.) [0]   
0=Ademco Low Speed; 1=Sescoa/Radionics
- \* 49 CHECKSUM VERIFICATION [0] [0]    
1=yes; 0=no Prim Sec
- \* 50 SESCOA/RADIONICS SELECT [0]   
1=Sescoa; 0=Radionics
- \* 51 DUAL REPORTING [0]   
1=yes; 0=no If used with Split Reporting "1" option (1\*34), alarms and alarm restores go to both primary & secondary numbers, while all other reports go to secondary only. If used with Split Reporting "2" option, alarms and alarm restores go to both, open/close and test messages go to secondary only, while all other reports go to primary. If used with Split Reporting "3" option, fire alarms and fire supervisory signals go to both primary and secondary, while all other reports go to secondary only.

- \* 52 STANDARD/EXPANDED REPORT FOR PRIMARY  
      [0]  
Alarm Rstr Bypass Trbl Opn/Cls Low Bat  
0=standard; 1=expanded; Note: Expanded overrides 4+2 format.
- \* 53 STANDARD/EXPANDED REPORT FOR SECONDARY  
      [0]  
Alarm Rstr Bypass Trbl Opn/Cls Low Bat  
0=standard; 1=expanded; Note: Expanded overrides 4+2 format.

**ZONE TYPE RESTORE ENABLES**

- \* 79 FOR ZONE TYPES 1-8 \*80 FOR TYPES 9/10  
           
1 2 3 4 5 6 7 8 9 10  
1=enable; [0=disable]

- \* 83 FIRST TEST REPORT TIME       
[Day 00; hour 12; min 00] Days 01-07 Hours 00-23 Min 00-59;  
00 in all boxes=instant (Day 01= Monday)
- \* 84 SWINGER SUPPRESSION [15]   
01-15 alarms; Must be "00" (disabled) for UL.
- \* 85 ENABLE DIALER REPORTS [0]      
FOR PANICS & DURESS 995 996 999 Duress  
1=enable; 0=disable
- \* 87 ENTRY WARNING [1]   
1=continuous; 0=3 beeps
- \* 88 BURGLAR ALARM COMM. DELAY [0]   
1=16 seconds; 0=no delay. Must be "0" for UL Commercial Burg.  
installations.
- \* 89 RESTORE REPORT TIMING [0]   
0=Instant; 1=After bell timeout if zone is restored; 2=when system  
is disarmed. Must be "0" for fire or UL Commercial Burg.
- \* 90 SEC. SUBS. ACCT #      
Enter 00-09; B-F (11-15) [15 15 15 15]
- 1\*17 LOBBY PARTITION [0]   
Enter the "common lobby" partition (1-8)
- 1\*18 AFFECTS LOBBY [0]   
Enter 1 if this partition affects the common lobby;  
enter 0 if it does not. Must be "0" for Commercial Fire & UL  
installations.
- 1\*19 ARMS LOBBY [0]   
Enter 1 if arming this partition attempts to arm lobby;  
enter 0 if it does not. Must be "0" for Commercial Fire & UL  
installations.

- 1\*20 EXIT ERROR LOGIC [0]   
0=No, 1=Bypass E/E and Interior zones faulted after  
exit delay. Must be "0" for Commercial Fire & UL installations.
- 1\*21 EXIT DELAY RESET [0]   
0=No; 1=Resets Exit Delay to 60 seconds after  
zone is closed. Must be "0" for Commercial Fire & UL  
installations.

FIELDS 1\*22-1\*25: Allow four sets of two zones each to be linked so that both must fault within a five minute period to cause an alarm.

- 1\*22 CROSS-ZONING PAIR ONE
- 1\*23 CROSS-ZONING PAIR TWO
- 1\*24 CROSS-ZONING PAIR THREE
- 1\*25 CROSS-ZONING PAIR FOUR

**MISCELLANEOUS WIRELESS OPTIONS**

**Fields 1\*28 - 1\*32 are not applicable to Commercial Fire or UL installations.**

- 1\*28 RF TX LOW BATTERY SOUND [0]   
1=immediate; 0=when disarmed;
- 1\*29 RF TX LOW BATTERY REPORT ENABLE [0]   
1=enable; 0=disable
- 1\*30 RF RCVR CHECK-IN INTERVAL [06]   
02-15 times 2 hours; 00 disables supervision
- 1\*31 RF TRANSMITTER CHECK-IN INTERVAL [12]    
02-15 times 2 hours; 00 disables transmitter supervision
- 1\*32 RF RECEIVER TYPE [0]   
1=4281; 2=5881
- 1\*33 TOUCH-TONE W/ROTARY BACKUP [0]   
1=enable; 0=disable
- 1\*34 COMM. SPLIT REPORT SELECTION [0]   
0=no; 1=alarms and alarm restores primary, others  
secondary; 2=open/close, test secondary, others primary; 3=  
fire alarms & troubles primary, all secondary. See \*51 for  
comments if using with dual reporting.
- 1\*42 CALL WAITING DEFEAT [0]   
1=Yes; 0=No.
- 1\*43 PERM. KEYPAD BACKLIGHT [0]   
1=enable; 0=disable When disabled, display lights when any  
key is pressed, and turns off after period of keypad inactivity.
- 1\*44 WIRELESS KEYPAD [0]   
TAMPER DETECT ENABLE 1=enable; 0=disable. Must  
be "0" for Commercial Fire and UL installations.
- 1\*45 EXIT DELAY SOUNDING [0]   
1=enable; 0=disable Produces quick beeping during exit delay  
if enabled.
- 1\*47 CHIME ON BELL 1 [0]   
1=enable; 0=disable
- 1\*48 WIRELESS KEYPAD ASSIGNMENT [0]   
0=disable; enter partition in which RF keypad used, 1-8. Must  
be "0" for Commercial Fire and UL installations.
- 1\*49 SUPPRESS TX SUPERVISION SOUND [1]   
1=disable; 0=enable. Must  
be "0" for Commercial Fire and UL installations.
- 1\*52 SEND CANCEL IF ALARM + OFF [0]   
1=no restriction; 0=within bell timeout period only



- 1\*53** DOWNLOAD CALLBACK [0]   
1=callback not required; 0=callback required; Must be "0" for Commercial Fire and UL installations.
- 1\*57** 5800 RF BUTTON GLOBAL ARM [0]   
Must be "0" for Commercial Fire and UL installations.
- 1\*58** 5800 RF BUTTON FORCE ARM [0]   
Enter "1" to enable. If a zone is faulted after pressing button, console will beep once. User should press button again within 4 sec. to force bypass those zones. Enter "0" to disable. Must be "0" for Commercial Fire and UL installations.
- 1\*60** ZONE 5 AUDIO ALARM VERIFICATION [0]   
Enter 1 If 2-way audio (AAV) is being used; Enter 0 if it is not. Must be "0" for Commercial Fire and UL installations.
- 1\*70** EVENT LOG TYPES        
1=enable; 0=disable Alarm Chk Byps O/C Syst Test Rpt
- 1\*71** 12/24 HOUR TIME STAMP FORMAT [0]   
0=12 hour; 1=24 hour
- 1\*72** EVENT LOG PRINTER ON-LINE [0]   
0=disable; 1=enable
- 1\*73** PRINTER BAUD RATE 1=300; 0=1200 [0]
- 1\*74** RELAY TIMEOUT XX MINUTES [000]     
Enter the relay timeout, **0-127** in multiples of 2 minutes, desired for #80 Menu Mode time driven event relay command numbers "04/09" and #93 Menu Mode Relay Programming output command "56".
- 1\*75** RELAY TIMEOUT YY SECONDS [000]     
Enter the relay timeout, **0-127** seconds, desired for #80 Menu Mode time driven event relay command numbers "05/10" and #93 Menu Mode Relay Programming command "57".
- 1\*76** ACCESS CONTROL RELAY FOR PART.[00]    
Relay will be pulsed for 2 seconds whenever code + [0] is pressed. Enter 00-16; 00=none. Must be "00" for Commercial Fire & UL..

### 3rd Page Programming Fields (press \*94)

- 2\*00** NUMBER OF PARTITIONS [1]   
Enter 1-8
- 2\*01** DAYLIGHT SAVINGS TIME [04, 10]      
START/END MONTH Start End  
00-12; if no daylight savings time, enter 00,00
- 2\*02** DAYLIGHT SAVINGS TIME [1, 5]    
START/END WEEKEND # Start | End  
Enter 1-7. 1=first; 2=second; 3=third; 4=fourth; 5=last; 6=next to last; 7=3rd from last [1,5; 1st Sunday in April, last in Oct.]
- 2\*05** AUTO-ARM DELAY [15]   
Enter the time between the end of the arming window and the start of auto-arming warning period, in values of 1-14 times 4 minutes 00=instant; [15=no auto arm at all]. When this delay expires, the Auto-Arm Warning Period begins.
- 2\*06** AUTO-ARM WARNING PERIOD [00]   
This is the time during which the user is warned to exit the premises prior to the auto-arming of the system (beeps every 15 seconds; "ALERT" displayed). Enter 01-15 minutes. 00=instant at end of arming delay .
- 2\*07** AUTO-DISARM DELAY [15]   
This is the time between the end of the disarming window and the start of auto-disarming. Enter 01-14 times 4 minutes; 00=instant at end of window; 15=no auto-disarm.
- 2\*08** ENABLE FORCE ARM FOR AUTO-ARM [0]   
0=disable; 1=enable

- 2\*09** OPEN/CLOSE REPORTS BY EXCEPTION [0]   
1=enable; 0=disable; If enabled, only openings and closings occurring outside the scheduled opening/closing windows will trigger dialer reports. Opening reports will also be suppressed during the closing window, in order to prevent false reports when the user arms the system and then reenters the premises to retrieve a forgotten item.
- 2\*10** ALLOW DISARMING ONLY DURING [0]   
ARMING/DISARMING WINDOWS  
0=disable; 1=enable  
See system-wide field 2\*11 if enabling field 2\*10. This feature adds high security to the installation.
- 2\*11** ALLOW DISARM OUTSIDE WINDOW [0]   
IF ALARM OCCURS  
Used only if field 2\*10 (partition-specific field) is set to "1". If this field is enabled ("1") the system can be disarmed outside the disarm window if an alarm has occurred. If "0", disarming can only be done during the disarm window. If field 2\*10 is set to "0" for a partition, this field has no effect for that partition.
- 2\*18** ENABLE GOTO FOR THIS PARTITION [0]   
1=Allow log-on from other partitions; 0=disable
- 2\*19** USE PARTITION DESCRIPTORS [0]   
0=disable; 1=enable
- 2\*20** ENABLE J2 TRIGGERS by PARTITION [1]   
0=disable for displayed partition; 1=enable for displayed partition
- 2\*21** ENABLE SUPERVISION PULSES FOR LRR TRIGGER OUTPUTS [000]     
Used for supervised connection to 7920SE. F B S  
Enter 0 to disable or 1 to enable the listed outputs. F= Fire; B= Burglary; S= Silent panic/duress. Enter 1 for Commercial Burglary and UL.
- 2\*22** DISPLAY FIRE ALARMS OF [0]   
OTHER PARTITIONS  
0=No; 1=Yes.
- 2\*23** DISPLAY BURG & PANIC ALARMS OF [0]   
OTHER PARTITIONS  
0=No; 1=Yes.
- 2\*24** DISPLAY TROUBLES OF OTHER [0]   
PARTITIONS  
0=No; 1=Yes.

### 4th Page Programming Fields (press \*94)

- 3\*00** DISPLAY TRBL INSTEAD OF CHECK [0]   
0=Check Displayed; 1=Trbl Displayed
- 3\*13** SUPV. N.O./N.C. SELECTION [0]   
0=Supv. on short/trouble on open; 1=supv. on short or open
- 3\*14** WATERFLOW SILENCE OPTION [1]   
0=Silence on Code + OFF; 1=Silence when waterflow restores
- 3\*15** ALARM BELL SOUND [1,0]    
0=pulsed; 1=steady Bell 1 Bell 2
- 3\*16** DELAY for ZONE TYPES 17 & 18 [00]    
(Waterflow & Fire Supv) Enter 00-15 times 2 seconds
- 3\*17** ALTERNATE FUNCTION (TAMPER) [0]   
FOR ZONE 6 0=disabled; 1=enabled
- 3\*18** EXTENDED DELAY FOR TYPES 17&18 [0]
- 3\*19** ENABLE J2 HEADER PRINTER PORT [0]   
0=pins 5&9 function as per field 3\*20; 1=pins 5&9 act as printer RXD & DTR



- 3\*20** TRIGGER OUTPUTS SELECTION [0]   
 0= LORRA full connection & Remote Console Sounder;  
 1=LORRA limited conn. & Keyswitch LEDs; 2=LORRA fire  
 only conn. & 5140LED
- 3\*21** MAX # OF DIALER ATTEMPTS [8]   
 1-8 (3, 4 or 5 for NFPA72 compliant systems when a  
 secondary phone number is programmed (field \*34)
- 3\*30** DIALER SELECTION [1,0]    
 1=enabled; 0=disabled Main Backup
- 3\*31** BACKUP DIALER TOUCHTONE/ROTARY [0]   
 1=TouchTone; 0=Rotary
- 3\*50** ZONE TYPE RESTORE ENABLES     
 FOR ZONE TYPES 16-18 16 17 18  
 1 = enabled; [0 = disabled]
- 3\*57** BELL 2 & AUX. RELAY CONFIRM    
 ARM DING Bell 2 AUX.  
 1=enable; [0=disable] . Must be 1 for UL Commercial  
 Burglary.
- 3\*58** BELL 2 & AUX. RELAY AC POWER    
 LOSS ALARM 1=yes; [0=no] (must be "1" for UL)
- 3\*59** ENABLE BELL 2 & AUX. RELAY    
 CHIME ANNUNCIATION Bell 2 AUX  
 1=enable; [0=disable]
- 3\*60** BELL 2 & AUX. RELAY TIMEOUT    
 00-15 times 2 minutes; 00=no timeout [00,00] Bell 2 AUX  
 Must be minimum of 16 minutes for UL Burglary installations.
- 3\*61** AUX. RELAY FUNCTION [1]   
 0=Trouble/supervisory; 1=Alarm, silenced by code + OFF  
 2=Smoke Detector Reset; 3=Battery Save; 4=Alarm, silenced  
 by code + [#] + 67
- 3\*82** ENABLE BURG. FEATURES ON PART. 1 [1]   
 1=enable; 0=disable; "0" disables AWAY, STAY, MAX,  
 TEST, INSTANT & CHIME functions
- 3\*85** ENABLE FIRE & SYSTEM ZONE BYPASS [1]   
 0=not enabled; 1=only installer can bypass; 2=only installer &  
 master user can bypass. Applies to fire zone types 9, 16, 17 &  
 18 and system zones 70-77. Applies to Partition 1 only.

## SUMMARY OF PROGRAMMING COMMANDS

- **To enter program mode**, enter installer code + [8] + [0] + [0]
- **To set standard defaults**, press \*97
- **To set communication defaults**, press \*94 + one of the following: \*80=low speed; \*81=Ademco Express; \*82=Ademco High Speed; \*83=Ademco's Contact ID
- **To change to next page of program fields**, press \*94
- **To return to previous set of fields**, press \*99
- **To erase account & phone number field entries**, press [\*] + field number + [\*]
- **To assign zone descriptors**, press #93 + follow menu prompts
- **To add custom words**, press #93 + follow menu prompts
- **To enter Installer's Message**, press #93 + follow menu prompts
- **To exit program mode**, press \*99 OR \*98: \*99 allows re-access to programming mode by installer code. \*98 prevents re-access to programming mode by installer code.

# VISTA 100 MULTIPLE PARTITION PROGRAMMING FORM

Some fields are programmed for each partition (shown as shaded fields). See the PARTITION-SPECIFIC section for programming these fields. Standard default (\*97) values are shown in brackets [ ], otherwise default = 0.

- \* 00** INSTALLER CODE [ ] [ ] [ ] [ ]  
Enter 4 digits, 0-9 [5140]
- \* 08** TEMPORAL SIREN PULSE [0] [ ]  
1 = Yes; 0 = No
- \* 09** ENTRY DELAY #1 Partition-Specific
- \* 10** EXIT DELAY #1 Partition-Specific
- \* 11** ENTRY DELAY #2 Partition-Specific
- \* 12** EXIT DELAY #2 Partition-Specific
- \* 13** BELL 1 TIMEOUT Partition-Specific
- \* 15** KEYSWITCH ASSIGNMENT [0] [ ]  
Enter partition in which keyswitch used, 1-8; 9=Silences bells if fire alarm present; 0=disable
- \* 16** BELL 1 CONFIRMATION OF ARMING DING Partition-Specific
- \* 17** AC LOSS KEYPAD SOUNDING [0] [ ]  
1=yes; 0=no
- \* 18** BELL 1 AC POWER LOSS ALARM [0] [ ]  
1=yes; 0=no. Must be "1" for UL Commercial Burglary.
- \* 19** RANDOMIZE AC LOSS REPORT [0] [ ]  
1=randomize 10-40 min.; 2=4-6 hrs; 0=when AC loss occurs. Must be "2" for Central Station and Remote Station fire alarm system.
- \* 20** VIP MODULE PHONE CODE [ ] [ ] [ ] [ ]  
Enter 01 - 09 for the first digit; enter [00] , [00] 11 for "\*" or 12 for "#" for the second digit. Must be "00, 00" for Commercial Fire & UL Commercial Burg. installations.
- \* 22** KEYPAD PANIC ENABLES Partition-Specific
- \* 23** MULTIPLE ALARMS Partition-Specific
- \* 24** IGNORE EXPANSION ZONE TAMPER [0] [ ]  
1=Ignore; 0=Enable tamper for RF and RPMs. Must be 0 for UL if these devices are used.
- \* 25** BURG.TRIGGER FOR RESPONSE TYPE 8 [1] [ ]  
1=enable; 0=disable
- \* 26** INTELLIGENT TEST REPORTING [0] [ ]  
1=yes, (no report sent if any other report was recently sent); 0=no. Must be "0" for Commercial Fire & UL Commercial Burglary installations.
- \* 27** TEST REPORT INTERVAL [024] [ ] [ ] [ ]  
Enter interval in hours, 001-999; 000=no report ; Max. 024 for Commercial Fire & UL.
- \* 28** POWER UP IN PREVIOUS STATE [1] [ ]  
1=yes; 0=no; "1" for UL.
- \* 29** QUICK ARM Partition-Specific
- \* 30** MAIN DIALER (TOUCHTONE OR ROTARY) [0] [ ]  
1=TouchTone; 0=rotary
- \* 31** PABX ACCESS CODE [ ] [ ] [ ] [ ] [ ] [ ]  
00-09; B-F (11-15)
- \* 32** PRIM. SUBS. ACCT # Partition-Specific
- \* 33** PRIMARY PHONE NUMBER [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]  
[ ] [ ] [ ] [ ] [ ] [ ]  
Enter 0-9 for each digit. Enter #11 for \*, #12 for #, #13 for 2 second pause.

- \* 34** SECONDARY PHONE NUMBER [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]  
[ ] [ ] [ ] [ ] [ ] [ ]  
Enter 0-9 for each digit. Enter #11 for \*, #12 for #, #13 for 2 second pause.
- \* 35** DOWNLOAD PHONE No. [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]  
[ ] [ ] [ ] [ ] [ ] [ ]  
Enter 0-9 for each digit. Enter #11 for \*, #12 for #, #13 for 2 second pause.
- \* 36** DOWNLOAD ID No. [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]  
Enter 00-09; A-F (10-15) [15 15 15 15 15 15 15 15]
- \* 37** DOWNLOAD COMMAND ENABLES [ ] [ ] [0] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]  
Dialer System Not Remote Remote Remote Upload Download  
Shutdwn Shutdwn Used Bypass Disarm Arm Program Program  
See field 1\*53 for Callback disable option; [1=enable]; 0=disable; For Commercial Fire & UL installations, all options must be disabled.
- \* 38** PREVENT ZONE XXX BYPASS Partition-Specific
- \* 39** OPEN/CLOSE REPORT FOR INSTALLER Partition-Specific
- \* 40** OPEN/CLOSE REPORT FOR KEYSWITCH [0] [ ]  
1=enable; 0=disable
- \* 41** NORMALLY CLOSED or EOLR (Zones 3-8) [1] [ ]  
1=N.C.loops; 0=EOLR supervision; Must be "0" for Commercial Fire & UL.
- \* 42** DIAL TONE PAUSE [0] [ ]  
0=5 seconds; 1=11 seconds; 2=30 seconds; Must be "0" for Commercial Fire & UL.
- \* 43** DIAL TONE DETECTION [1] [ ]  
1=wait for true dial tone; 0=pause, then dial
- \* 44** RING DETECTION COUNT [00] [ ] [ ]  
01-14; 15=answering machine; 00=no detection. Must be "0" for Commercial Fire & UL Burglary.
- \* 45** PRIMARY FORMAT [0] [ ]  
0=Low Speed; 1=Contact ID; 2=Ademco High Speed; 3=Ademco Express
- \* 46** LOW SPEED FORMAT (Primary) [0] [ ]  
0=Ademco Low Speed; 1=Sescoa/Radionics
- \* 47** SECONDARY FORMAT [0] [ ]  
0=Low Speed; 1=Contact ID; 2=Ademco High Speed; 3=Ademco Express
- \* 48** LOW SPEED FORMAT (Sec.) [0] [ ]  
0=Ademco Low Speed; 1=Sescoa/Radionics
- \* 49** CHECKSUM VERIFICATION [0] [0] [ ] [ ]  
1=yes; 0=no PrimScndry
- \* 50** SESCOA/RADIONICS SELECT [0] [ ]  
1=Sescoa; 0=Radionics

**\* 51 DUAL REPORTING** [0]

1=yes; 0=no If used with Spilt Reporting "1" option (1\*34), alarms and alarm restores go to both primary & secondary numbers, while all other reports go to secondary only. If used with Split Reporting "2" option, alarms and alarm restores go to both, open/close and test messages go to secondary only, while all other reports go to primary. If used with Split Reporting "3" option, fire alarms and fire supervisory signals go to both primary and secondary, while all other reports go to secondary only.

**\* 52 STANDARD/EXPANDED REPORT FOR PRIMARY**

[0]  
Alarm Rstr Bypass Trbl Opn/Cls Low Bat

0=standard; 1=expanded; Note: Expanded overrides 4+2 format.

**\* 53 STANDARD/EXPANDED REPORT FOR SECONDARY**

[0]  
Alarm Rstr Bypass Trbl Opn/Cls Low Bat

0=standard; 1=expanded; Note: Expanded overrides 4+2 format.

**ZONE TYPE RESTORE ENABLES**

1=enable; [0]=disable

**\* 79 FOR ZONE TYPES 1-8** **\*80 FOR TYPES 9/10**

1 2 3 4 5 6 7 8 9 10

**\* 83 FIRST TEST REPORT TIME**

[Day 00; hour 12; min 00] Days 01-07 Hours 00-23 Min 00-59; 00 in all boxes=instant (Day 01= Monday)

**\* 84 SWINGER SUPPRESSION** Partition-Specific

**\* 85 ENABLE DIALER REPORTS FOR PANICS & DURESS** Partition-Specific

**\* 87 ENTRY WARNING** Partition-Specific

**\* 88 BURG. ALARM COMM. DELAY** Partition-Specific

**\* 89 RESTORE REPORT TIMING** [0]

0=instant; 1=at bell timeout; 2=at diarm. Must be "0" for fire or UL installations.

**\* 90 2nd SUBS. ACCT #**

**1\*17 LOBBY PARTITION** [0]

Enter the "common lobby" partition (1-8)

**1\*18 AFFECTS LOBBY** Partition-Specific

**1\*19 ARMS LOBBY** Partition-Specific

**1\*20 EXIT ERROR LOGIC** [0]

0=No, 1=Bypass E/E and Interior zones faulted after exit delay. Must be "0" for UL Commercial Burglary.

**1\*21 EXIT DELAY RESET** [0]

0=No; 1=Resets Exit Delay to 60 seconds after zone is closed. Must be "0" for Commercial Fire and UL installations.

FIELDS 1\*22-1\*25: Allow four sets of two zones each to be linked so that both must fault within a five minute period to cause an alarm. Must be 0 for UL Burglary.

**1\*22 CROSS-ZONING PAIR ONE**

**1\*23 CROSS-ZONING PAIR TWO**

**1\*24 CROSS-ZONING PAIR THREE**

**1\*25 CROSS-ZONING PAIR FOUR**

**MISCELLANEOUS WIRELESS OPTIONS**

**Fields 1\*28 - 1\*32 are not applicable to Commercial Fire or UL installations.**

**1\*28 RF TX LOW BATTERY SOUND** [0]

1=immediate; 0=when disarmed.

**1\*29 RF TX LOW BATTERY REPORT ENABLE** [0]

1=enable; 0=disable

**1\*30 RF RCVR CHECK-IN INTERVAL** [06]

02-15 times 2 hours; 00 disables supervision.

**1\*31 RF XMitter CHECK-IN INTERVAL** [12]

02-15 times 2 hours; 00 disables transmitter supervision.

**1\*32 RF RECEIVER TYPE** [0]

1=4281; 2=5881

**1\*33 TOUCH-TONE W/ROTARY BACKUP** [0]

1=enable; 0=disable

**1\*34 COMM. SPLIT REPORT SELECTION** [0]

0=no; 1=alarms and alarm restores primary, others secondary; 2=open/close, test secondary, others primary; 3= fire alarms & troubles primary, all secondary. See \*51 for comments if using with dual reporting.

**1\*42 CALL WAITING DEFEAT** [0]

1=Yes; 0=No.

**1\*43 PERM. KEYPAD BACKLIGHT** Partition-Specific

**1\*44 WIRELESS KEYPAD** [0]

TAMPER DETECT ENABLE 1=enable; 0=disable  
Must be "0" for Commercial Fire & UL installations.

**1\*45 EXIT DELAY SOUNDING** Partition-Specific

**1\*47 CHIME ON BELL 1** Partition-Specific

**1\*48 WIRELESS KEYPAD ASSIGNMENT** [0]

0=disable; enter partition in which RF keypad used, 1-8. Must be "0" for Commercial Fire & UL installations.

**1\*49 SUPPRESS TX SUPERVISION SOUND** [1]

1=disable; 0=enable. Must be "0" for Commercial Fire & UL installations.

**1\*52 SEND CANCEL IF ALARM + OFF** Partition-Specific

**1\*53 DOWNLOAD CALLBACK** [0]

1=callback not required; 0=callback required; Must be "0" for Commercial Fire & UL installations.

**1\*57 5800 RF BUTTON GLOBAL ARM** [0]

Enter "1" to have the system arm/disarm following the button user's global arm settings. Enter "0" if the button is not to be used to global arm the system. Must be "0" for Commercial Fire & UL installations.

**1\*58 5800 RF BUTTON FORCE ARM** [0]

Enter "1" to enable. If a zone is faulted after pressing button, console will beep once. User should press button again within 4 sec. to force bypass those zones. Enter "0" to disable. Must be disabled for UL Listed installations.

**1\*60 ZONE 5 AUDIO ALARM VERIFICATION** [0]

Enter 1 if 2-way audio (AAV) is being used; Enter 0 if it is not. Must be "0" for Commercial Fire & UL installations.

**1\*70 EVENT LOG TYPES**

1=enable; 0=disable Alrm Chck Byps O/C Syst Test Rpt

**1\*71 12/24 HOUR TIME STAMP FORMAT** [0]

0=12 hour; 1=24 hour

**1\*72 EVENT LOG PRINTER ON-LINE** [0]

0=disable; 1=enable

- 1\*73 PRINTER BAUD RATE 1=300; 0=1200 [0]
- 1\*74 RELAY TIMEOUT XX MINUTES [000]     
Enter the relay timeout, 0-127 in multiples of 2 minutes, desired for #80 Menu Mode time driven event relay command numbers "04/09" and #93 Menu Mode Relay Programming output command "56".
- 1\*75 RELAY TIMEOUT YY SECONDS [000]     
Enter the relay timeout, 0-127 seconds, desired for #80 Menu Mode time driven event relay command numbers "05/10" and #93 Menu Mode Relay Programming command "57".
- 1\*76 ACCESS CONTROL RELAY Partition-Specific FOR PARTITION

### 3rd Page Programming Fields (press \*94)

- 2\*00 NUMBER OF PARTITIONS [1]   
Enter 1-8
- 2\*01 DAYLIGHT SAVINGS TIME [04, 10]      
START/END MONTH Start End  
00-12; if no daylight savings time, enter 00,00
- 2\*02 DAYLIGHT SAVINGS TIME [1, 5]    
START/END WEEKEND # Start | End  
Enter 1-7. 1=first; 2=second; 3=third; 4=fourth; 5=last; 6=next to last; 7=3rd from last [1,5; 1st Sunday in April, last in Oct.]
- 2\*05 AUTO-ARM DELAY Partition-Specific
- 2\*06 AUTO-ARM WARNING PERIOD Partition-Specific
- 2\*07 AUTO-DISARM DELAY Partition-Specific
- 2\*08 ENABLE FORCE ARM FOR AUTO-ARM Partition-Specific
- 2\*09 ENABLE OPEN/CLOSE REPORTS BY EXCEPTION Partition-Specific
- 2\*10 ALLOW DISARMING ONLY DURING ARMING/DISARMING WINDOWS Partition-Specific
- 2\*11 ALLOW DISARM OUTSIDE WINDOW IF ALARM OCCURS [0]   
Used only if field 2\*10 (partition-specific field) is set to "1". If this field is enabled ("1") the system can be disarmed outside the disarm window if an alarm has occurred. If "0", disarming can only be done during the disarm window. If field 2\*10 is set to "0" for a partition, this field has no effect for that partition.
- 2\*18 ENABLE GOTO FOR THIS PARTITION Partition-Specific
- 2\*19 USE PARTITION DESCRIPTORS [0]   
0=disable; 1=enable
- 2\*20 ENABLE J2 TRIGGERS FOR THIS PARTITION Partition-Specific
- 2\*21 ENABLE SUPERVISION PULSES FOR LRR TRIGGER OUTPUTS [000]     
Used for supervised connection to 7920SE. F B S  
Enter 0 to disable or 1 to enable the listed outputs.  
F= Fire; B= Burglary; S= Silent panic/duress. Must be "1" for Commercial Fire & UL.
- 2\*22 DISPLAY FIRE ALARMS OF OTHER PARTITIONS Partition-Specific
- 2\*23 DISPLAY BURG & PANIC ALARMS OF OTHER PARTITIONS Partition-Specific
- 2\*24 DISPLAY TROUBLES OF OTHER PARTITIONS Partition-Specific

### 4th Page Programming Fields (press \*94)

- 3\*00 DISPLAY TRBL INSTEAD OF CHECK [0]   
0=Check Displayed; 1=Trbl Displayed
- 3\*13 SUPV. N.O./N.C. SELECTION [0]   
0=Supv. on short/trouble on open; 1=supv. on short or open
- 3\*14 WATERFLOW SILENCE OPTION [1]   
0=Silence on Code + OFF; 1=Silence when waterflow restores. This feature may only be set to "1" by permission of the local authority.
- 3\*15 ALARM BELL SOUND [1,0]    
0=pulsed; 1=steady Bell 1 Bell 2
- 3\*16 DELAY for ZONE TYPES 17 & 18 [00]    
(Waterflow & Fire Supv) Enter 00-15 times 2 seconds
- 3\*17 ALTERNATE FUNCTION (TAMPER) [0]   
FOR ZONE 6 0=disabled; 1=enabled
- 3\*18 EXTENDED DELAY FOR TYPES 17&18 [0]
- 3\*19 ENABLE J2 HEADER PRINTER PORT [0]   
0=pins 5&9 function as per field 3\*20; 1=pins 5&9 act as printer RXD & DTR
- 3\*20 TRIGGER OUTPUTS SELECTION [0]   
0= LORRA full connection & Remote Console Sounder; 1=LORRA limited conn. & Keypad LEDs; 2=LORRA fire only conn. & 5140LED
- 3\*21 MAX # OF DIALER ATTEMPTS [8]   
1-8 (3, 4 or 5 for NFPA72 compliant systems when a secondary phone number is programmed (field \*34)
- 3\*30 DIALER SELECTION [1,0]    
1=enabled; 0=disabled Main Backup
- 3\*31 BACKUP DIALER TOUCHTONE/ROTARY [0]   
1=TouchTone; 0=Rotary
- 3\*50 ZONE TYPE RESTORE ENABLES     
FOR ZONE TYPES 16-18 16 17 18  
Must be "1" for Commercial Fire & UL installations.
- 3\*57 BELL 2 & AUX. RELAY CONFIRMATION OF ARM DING Partition-Specific
- 3\*58 BELL 2 & AUX. RELAY AC POWER    
LOSS ALARM 1=yes; [0=no] Bell 2 AUX.Relay
- 3\*59 ENABLE BELL 2 & AUX. RELAY CHIME ANNUNCIATION Partition-Specific
- 3\*60 BELL 2 & AUX. RELAY TIMEOUT Partition-Specific
- 3\*61 AUX. RELAY FUNCTION [1]   
0=Trouble/supervisory; 1=Alarm, silenced by code + OFF  
2=Smoke Detector Reset; 3=Battery Save; 4=Alarm, silenced by code + [#] + 67
- 3\*82 ENABLE BURG. FEATURES ON PART. 1 [1]   
1=enable; 0=disable; "0" disables AWAY, STAY, MAX, TEST, INSTANT & CHIME functions
- 3\*85 ENABLE FIRE & SYSTEM ZONE BYPASS [1]   
0=not enabled; 1=only installer can bypass; 2=only installer & master user can bypass. Applies to fire zone types 9, 16, 17 & 18 and system zones 70-77. Applies to Partition 1 only.

## PARTITION-SPECIFIC FIELDS

(Duplicate this page for each partition in the installation.)

### To program these fields,

1. Press \*91 to select a partition.
2. Enter a partition-specific field number (ex. \*09).
3. Make the required entry.
4. Repeat steps 1-3 for each partition in the system.

### PARTITION # \_\_\_\_\_ PROGRAM FIELDS

#### 1st Page Fields

- \* 09** ENTRY DELAY #1 [02]   |  
 00-15 times 15 seconds  
 Maximum 03 for UL Listed installations.
- \* 10** EXIT DELAY #1 [03]   |  
 00-15 times 15 seconds  
 Maximum 04 for UL Listed installations.
- \* 11** ENTRY DELAY #2 [06]   |  
 00-15 times 15 seconds  
 Maximum 03 for UL Commercial Burglary installations.
- \* 12** EXIT DELAY #2 [08]   |  
 00-15 times 15 seconds  
 Maximum 04 for UL Commercial Burglary installations.
- \* 13** BELL 1 TIMEOUT [04]   |  
 01-15 times 2 minutes. Minimum 16 minutes for UL Commercial Burglary and 6 minutes for Commercial Fire installations.
- \* 16** CONFIRMATION OF ARMING DING [0]   
 1=enable; 0=disable. Must be "1" for UL Commercial Burglary installations.
- \* 22** KEYPAD PANIC ENABLES [001]      
 1=enable; 0=disable 995 996 999
- \* 23** MULTIPLE ALARMS [1]   
 1=yes; 0=no. Enter 1 for Commercial Fire & UL Commercial Burglary installations.
- \* 29** QUICK ARM [1]   
 1=yes; 0=no
- \* 32** PRIM. SUBS. ACCT #       
 Enter 00-09; B-F (11-15) [15 15 15 15]
- \* 38** PREVENT ZONE XXX BYPASS [000]     
 001-087; 00 if all zones (except Fire zones) can be bypassed
- \* 39** ENABLE OPEN/CLOSE REPORT FOR INSTALLER CODE [0]   
 1=enable; 0=disable
- \* 84** SWINGER SUPPRESSION [15]   |  
 01-15 alarms; Must be "00" (disabled) for Commercial Fire & UL installations..
- \* 85** ENABLE DIALER REPORTS FOR PANICS & DURESS [0]       
 995 996 999 Duress  
 1=enable; 0=disable
- \* 87** ENTRY WARNING [1]   
 1=continuous; 0=3 beeps
- \* 88** BURG. ALARM COMM. DELAY [0]   |  
 1=16 seconds; 0=no delay. Must be "0" for UL Commercial Burglary installations.
- \* 90** SEC. SUBS. ACCT #       
 Enter 00-09; B-F (11-15) [15 15 15 15]

- 1 \* 18** AFFECTS LOBBY [0]   
 Enter 1 if this partition affects the common lobby; enter 0 if it does not.

- 1 \* 19** ARMS LOBBY [0]   
 Enter 1 if arming this partition attempts to arm lobby; enter 0 if it does not

#### 2nd Page Fields

- 1 \* 43** PERM. KEYPAD BACKLIGHT [0]   
 1=enable; 0=disable When disabled, display lights when any key is pressed, and turns off after period of keypad inactivity.
- 1 \* 45** EXIT DELAY SOUNDING [0]   
 1=enable; 0=disable Produces quick beeping during exit delay if enabled.
- 1 \* 47** CHIME ON BELL 1 [0]   
 1=enable; 0=disable
- 1 \* 52** SEND CANCEL IF ALARM + OFF [0]   
 1=no restriction; 0=within Bell Timeout period only
- 1 \* 76** ACCESS CONTROL RELAY FOR PART. [00]   |  
 Relay will be pulsed for 2 seconds whenever code + [0] is pressed. Enter 00-16; 00=none. Must be "00" for Commercial Fire & UL.

#### 3rd Page Fields

- 2 \* 05** AUTO-ARM DELAY [15]   
 Enter the time between the end of the arming window and the start of auto-arming warning period, in values of 1-14 times 4 minutes 00=instant; [15=no auto arm at all]. When this delay expires, the Auto-Arm Warning Period begins.
- 2 \* 06** AUTO-ARM WARNING PERIOD [00]   
 This is the time during which the user is warned to exit the premises prior to the auto-arming of the system (beeps every 15 seconds; "ALERT" displayed). Enter 01-15 minutes. 00=instant at end of arming delay .
- 2 \* 07** AUTO-DISARM DELAY [15]   
 This is the time between the end of the disarming window and the start of auto-disarming. Enter 01-14 times 4 minutes; 00=instant at end of window; 15=no auto-disarm.
- 2 \* 08** ENABLE FORCE ARM FOR AUTO-ARM [0]   
 0=disable; 1=enable.
- 2 \* 09** OPEN/CLOSE REPORTS BY EXCEPTION [0]   
 1=enable; 0=disable; If enabled, only openings and closings occurring outside the scheduled opening/closing windows will trigger dialer reports. Opening reports will also be suppressed during the closing window, in order to prevent false reports when the user arms the system and then reenters the premises to retrieve a forgotten item.
- 2 \* 10** ALLOW DISARMING ONLY DURING ARMING/DISARMING WINDOWS [0]   
 See system-wide field 2\*11 if enabling field 2\*10. This feature adds high security to the installation.  
 0=disable; 1=enable
- 2 \* 18** ENABLE GOTO FOR THIS PARTITION [0]   
 1=Allow log-on from other partitions; 0=disable



- 2\*20** ENABLE J7 TRIGGERS by PARTITION [1]   
 0=disable for displayed partition; 1=enable for displayed partition
- 2\*22** DISPLAY FIRE ALARMS OF OTHER PARTITIONS [0]   
 0=No; 1=Yes
- 2\*23** DISPLAY BURG/PANIC ALARMS OF OTHER PARTITIONS [0]   
 10=No; 1=Yes
- 2\*24** DISPLAY TROUBLES OF OTHER PARTITIONS [0]   
 0=No; 1=Yes

**4th Page Fields**

- 3\*57** BELL 2 & AUX. RELAY CONFIRM    
 ARM. DING 1=enable; [0=disable] Must be "1" for UL. Bell 2 Relay
- 3\*59** ENABLE BELL 2 & AUX. RELAY CHIME ANNUNCIATION    
 1=enable; [0=disable] Bell 2 Relay
- 3\*60** BELL 2 & AUX. RELAY TIMEOUT    
 00-15 times 2 minutes; 00=no timeout [00,00] Bell 2 Relay  
 Minimum 16 min. for UL Burglary installations.

**SUMMARY OF PROGRAMMING COMMANDS**

- **To enter program mode**, enter installer code + [8] + [0] + [0]
- **To set standard defaults**, press \*97
- **To set communication defaults**, press \*94 + one of the following: \*80=low speed; \*81=Ademco Express; \*82=Ademco High Speed; \*83=Ademco's Contact ID
- **To change to next page of program fields**, press \*94
- **To return to previous set of fields**, press \*99
- **To erase account & phone number field entries**, press [\*] + field number + [\*]
- **To assign zone descriptors**, press #93 + follow menu prompts
- **To add custom words**, press #93 + follow menu prompts
- **To enter Installer's Message**, press #93 + follow menu prompts
- **To exit program mode**, press \*99 OR \*98: \*99 allows re-access to programming mode by installer code. \*98 prevents re-access to programming mode by installer code.



## PROGRAMMING WITH #93 MENU MODE

**NOTE: The following fields should be preset before beginning: 2\*00 Number of Partitions; 1\*32 receiver type. In addition, receivers should be programmed via Device programming.**

After programming all system related programming fields in the usual way, press #93 while still in programming mode to display the first choice of the menu driven programming functions. Press 0 (NO) or 1 (YES) in response to the displayed menu selection. Pressing 0 will display the next choice in sequence. Menu selections are as follows:

<b>ZONE PROG?</b> 0=No    1=Yes
------------------------------------

For programming the following:

- Zone Number
- Zone Response Type
- Hardwired zone
- RF Zone
- Right/left Loop Zone
- Serial number RPM zone
- Partition Number for Zone
- Dialer report code for zone

<b>SERIAL PROG?</b> 0=no    1=yes
--------------------------------------

For entering (learning) 5800 transmitter & serial number polling loop device serial numbers into the system.

<b>REPORT CODE PROG</b> 0 = no; 1 = yes
--

For entering report codes for zones and all system conditions.

<b>ALPHA PROG?</b> 0=no    1=yes
-------------------------------------

For entering alpha descriptors for the following:

- Zone Descriptors
- Installer's Message
- Custom Words
- Partition Descriptors
- Relay Descriptors

<b>DEVICE PROG?</b> 0=no    1=yes
--------------------------------------

For defining the following device characteristics for addressable devices, including consoles, RF receivers (4281/5881), 4285 voice module and 4204 output relay modules:

- Device Address
- Device Type
- Device's Home Partition
- Console Options
- Voice Module

<b>RELAY PROG?</b> 0=no    1=yes
-------------------------------------

For defining output relay functions.

<b>RLY VOICE DESCR?</b> 0=no    1=yes
--

For entering voice descriptors to be used with voice module functions.

<b>CUSTOM INDEX #?</b> 0=no    1=yes
---

For creating custom word substitutes for voice module annunciation.

### #93 MENU MODE KEY COMMANDS

The following is a list of commands used while in the menu mode.

#93	Enters Menu mode
[*]	Serves as ENTER key. Press to have console accept entry.
[#]	Backs up to previous screen.
0	Press to answer NO
1	Press to answer YES
01-09	All data entries are 2-digit entries.
00	Escapes from menu mode, back into field programming mode, when entered at the first question for each category.

# SYSTEM LAYOUT WORKSHEETS

As with any security system, you should first define the installation. This includes determining how many partitions will be used, how many zones per partition, and how many users per partition. You will also need to determine what peripheral devices will be needed, and basic system options such as exit/entry delays, etc. The control panel itself should be located in an area that will facilitate wire runs to all partitions, and will allow access to power and telephone circuits.

**To help you lay out a partitioned system, use the following worksheet. This will further simplify the programming process.**

PARTITIONS				
Partition #	Descriptor (4 char max)	Prim. Sub. #	Sec. Sub. #	Alpha Default Message (32 character maximum)
Partition 1				
Partition 2				
Partition 3				
Partition 4				
Partition 5				
Partition 6				
Partition 7				
Partition 8				
Keyswitch Arming Partition Assignment (1-8 or 9):				
Wireless Keypad Partition Assignment (1-8):				
Voice Module Partition Assignment (1-8):				
Use Partition Descriptor (yes/no)?				
Common Lobby Partition Assignment (1-8):				

COMMUNICATION OPTIONS BY PARTITION (enter yes/no)								
Option	part 1	part. 2	part. 3	part. 4	part. 5	part. 6	part. 7	part. 8
Swinger Suppression Count 00-15; 00=no suppression								
Cancel Report After Disarm								
Dialer Reports for Panic (* + 1)								
Dialer Reports for Panic (# + 3)								
Dialer Reports for Panic (* + #)								
Dialer Reports for Duress								
Burglary Alarm Communications Delay (16 sec.)								

**SYSTEM DEFINITIONS BY PARTITION (enter values or yes/no)**

<b>Option</b>	<b>part 1</b>	<b>part. 2</b>	<b>part. 3</b>	<b>part. 4</b>	<b>part. 5</b>	<b>part. 6</b>	<b>part. 7</b>	<b>part. 8</b>
Entry Delay #1 (15-225 seconds):								
Exit Delay #1 (15-225 seconds):								
Entry Delay #2 (15-225 seconds):								
Exit Delay #2 (15-225 seconds):								
Quick Arming								
Multiple Alarms per Arming								
Console Panic for zone 95 (* + 1)								
Console Panic for zone 96 (# + 3)								
Console Panic for zone 99 (* + #)								
Allow Sign-on (GOTO function)								
Non-Bypassable Zone*								
Sounder Timeout Duration for Bell 1 (2 min. increments)								
Sounder Timeout Duration for Bell 2 & Aux Rly (2 min. increments)								
Console Annunciation During Entry**								
Console Annunciation During Exit								
Confirmation of Arming Ding for Bell 1								
Confirmation of Arming Ding for Bell 2 & Aux Rly								
Chime on Bell 1								
Chime on Bell 2 & Aux Relay								
Access Control Relay (field 1*76)								
Affects Lobby (check partitions that apply)								
Arms Lobby (check partitions that apply)								
Displays Fire Alarms of Other Partitions								
Displays Burg & Panic Alarms of Other Partitions								
Displays Troubles of Other Partitions								

\*Can be any zone 1-87.

\*\*no= 3 beeps yes=continuous

DEVICES (Consoles, 4204, etc.)									
Device Address	Type	Home Partition	Sounder Option	Supervised CF?	Device Address	Type	Home Partition	Sounder Option	Supervised CF?
00					16				
01					17				
02					18				
03					19				
04					20				
05					21				
06					22				
07					23				
08					24				
09					25				
10					26				
11					27				
12					28				
13					29				
14					30				
15					31				

**Type:**

- 0 = device not used
- 1 = alpha console
- 2 = fixed-word console
- 3 = RF receiver
- 4 = Output Relay module
- 5 = Voice Module

**Console Sounder Options:**

- 00 = no suppression
- 01 = suppress arm/disarm and entry/exit beeps
- 02 = suppress chime mode beeps only
- 03 = suppress arm/disarm, entry/exit and chime mode beeps

**ACCESS CODES & USER DEFINITIONS FOR PARTITIONS 1-3**

4-digit Security Code	Access Group 0; 1-8	Partition 1				Partition 2				Partition 3			
		2-digit user #	Global Arm?	Auth. level	open/close	2-digit user #	Global Arm?	Auth. level	open/close	2-digit user #	Global Arm?	Auth. level	open/close

**ACCESS CODES & USER DEFINITIONS FOR PARTITIONS 4-6**

4-digit Security Code	Access Group 0; 1-8	Partition 4				Partition 5				Partition 6			
		2-digit user #	Global Arm?	Auth. level	open/close	2-digit user #	Global Arm?	Auth. level	open/close	2-digit user #	Global Arm?	Auth. level	open/close

**ACCESS CODES & USER DEFINITIONS FOR PARTITIONS 7 & 8**

4-digit Security Code	Access Group 0; 1-8	Partition 7				Partition 8				NOTES:
		2-digit user #	Global Arm?	Auth. level	open/close	2-digit user #	Global Arm?	Auth. level	open/close	

Authority Levels:    1=master (arm, disarm, bypass, and/or modify lower level users)  
                           2=manager (arm, disarm, bypass, and/or modify lower level users)  
                           3=operator A (arm, disarm, bypass)  
                           4=operator B (arm, disarm)  
                           5=operator C (arm, disarm only if system was armed with this code)  
                           6=duress code (arm, disarm, triggers silent panic alarm)

**ZONE DEFINITIONS FOR ZONES 1-24**

Zone No.	Zone Type	Parti-tion (1-8)	RF Trans. Type†			DIP RPM left loop	DIP RPM right loop	Ser. RPM†	Hard Wired	Report Code	† Enter loop number on module
			RF (3)	UR (4)	BR (5)						Loop number must be 1 for hardwire and DIP devices) Zone Information (part numbers) & Alpha Descriptor (3 words max.)
1											
2											
3											
4											
5											
6											
7											
8											
9											
10											
11											
12											
13											
14											
15											
16											
17											
18											
19											
20											
21											
22											
23											
24											



**ZONE DEFINITIONS FOR ZONES 25-48**

Zone No.	Zone Type	Parti- tion (1-8)	RF Trans. Type†			DIP RPM left loop	DIP RPM right loop	Ser. RPM†	Hard Wired	Report Code	†Enter loop number on module
			RF (3)	UR (4)	BR (5)						Loop number must be 1 for hardwire and DIP devices) Zone Information (part numbers) & Alpha Descriptor (3 words max.)
25											
26											
27											
28											
29											
30											
31											
32											
33											
34											
35											
36											
37											
38											
39											
40											
41											
42											
43											
44											
45											
46											
47											
48											

**ZONE DEFINITIONS FOR ZONES 49-72**

Zone No.	Zone Type	Parti-tion (1-8)	RF Trans. Type†			DIP RPM left loop	DIP RPM right loop	Ser. RPM†	Hard Wired	Report Code	<div style="border: 1px solid black; padding: 2px; display: inline-block;">† Enter loop number on module</div> Loop number must be 1 for hardwire and DIP devices) Zone Information (part numbers) & Alpha Descriptor (3 words max.)
			RF (3)	UR (4)	BR (5)						
49											
50											
51											
52											
53											
54											
55											
56											
57											
58											
59											
60											
61											
62											
63											
64											
65											
66											
67											
68											
69											
70											
71											
72											

**ZONE DEFINITIONS FOR ZONES 73-86**

Zone No.	Zone Type	Parti-tion (1-8)	RF Trans. Type†			DIP RPM left loop	DIP RPM right loop	Ser. RPM†	Hard Wired	Report Code	† Enter loop number on module Loop number must be 1 for hardwire and DIP devices) Zone Information (part numbers) & Alpha Descriptor (3 words max.)
			RF (3)	UR (4)	BR (5)						
73											
74											
75											
76											
77											
78											
79											
80											
81											
82											
83											
84											
85											
86											
87											

Zone Types:

00=zone not used	06=24 hour silent	17=Fire Supervisory
01=entry/exit 1	07=24 hour audible	18=Fire Supervisory
02=entry/exit 2	08=24 hour auxiliary	19=24 hour trouble
03=perimeter	09=supervised fire	20=arm stay
04=interior (follower)	10=interior (delay)	21=arm away
05=day/night burglary	16=Fire w/Verification	22=disarm
		23=no alarm response

PRINTER OPTIONS	
12 or 24 hour Time format	
Printer On-Line (yes/no)	
1200 or 300 baud Printer Baud Rate	

EVENT LOG TYPES		
Option	No (4)	Yes (4)
Alarm		
Trouble		
Bypass		
Open/Close		
System		
Test Report		



**ALARM DEVICE MANUFACTURING CORPORATION**  
A DIVISION OF PITTMWAY CORPORATION  
**165 Eileen Way, Syosset, New York 11791**  
Copyright © 1996 PITTMWAY CORPORATION